

# vscholl\_week3

June 27, 2018

```
In [1]: # check python version
import sys
sys.version
```

```
Out[1]: '3.6.5 |Anaconda, Inc.| (default, Apr 26 2018, 08:42:37) \n[GCC 4.2.1 Compatible Clang
```

```
In [2]: # import necessary libraries: gdal, numpy, matplotlib
#!conda install gdal
import gdal
import numpy as np
import matplotlib.pyplot as plt
%matplotlib inline
import warnings
warnings.filterwarnings('ignore')
```

```
In [3]: def RGBraster2array(RGB_geotif):
        """RGBraster2array reads in a NEON AOP geotif file and returns
        a numpy array, and header containing associated metadata with spatial information.
        -----
        Parameters
            RGB_geotif -- full or relative path and name of reflectance hdf5 file
        -----
        Returns
        -----
        array:
            numpy array of geotif values
        metadata:
            dictionary containing the following metadata (all strings):
                array_rows
                array_cols
                bands
                driver
                projection
                geotransform
                pixelWidth
                pixelHeight
                extent
                noDataValue
```

*scaleFactor*

*Example Execution:*

```
RGB_geotif = '2017_SERC_2_368000_4306000_image.tif'  
RGBcam_array, RGBcam_metadata = RGBraster2array(RGB_geotif) """
```

```
metadata = {}  
dataset = gdal.Open(RGB_geotif)  
metadata['array_rows'] = dataset.RasterYSize  
metadata['array_cols'] = dataset.RasterXSize  
metadata['bands'] = dataset.RasterCount  
metadata['driver'] = dataset.GetDriver().LongName  
metadata['projection'] = dataset.GetProjection()  
metadata['geotransform'] = dataset.GetGeoTransform()  
  
mapinfo = dataset.GetGeoTransform()  
metadata['pixelWidth'] = mapinfo[1]  
metadata['pixelHeight'] = mapinfo[5]  
  
metadata['ext_dict'] = {}  
metadata['ext_dict']['xMin'] = mapinfo[0]  
metadata['ext_dict']['xMax'] = mapinfo[0] + dataset.RasterXSize/mapinfo[1]  
metadata['ext_dict']['yMin'] = mapinfo[3] + dataset.RasterYSize/mapinfo[5]  
metadata['ext_dict']['yMax'] = mapinfo[3]  
  
metadata['extent'] = (metadata['ext_dict']['xMin'], metadata['ext_dict']['xMax'],  
                     metadata['ext_dict']['yMin'], metadata['ext_dict']['yMax'])  
  
raster = dataset.GetRasterBand(1)  
array_shape = raster.ReadAsArray(0,0,metadata['array_cols'], metadata['array_rows'])  
metadata['noDataValue'] = raster.GetNoDataValue()  
metadata['scaleFactor'] = raster.GetScale()  
  
array = np.zeros((array_shape[0], array_shape[1], dataset.RasterCount), 'uint8') #pre  
for i in range(1, dataset.RasterCount+1):  
    band = dataset.GetRasterBand(i).ReadAsArray(0,0,metadata['array_cols'], metadata['array_rows'])  
    band[band==metadata['noDataValue']] = np.nan  
    band = band/metadata['scaleFactor']  
    array[...,i-1] = band  
  
return array, metadata
```

```
In [4]: RGB_geotif = './2017_SERC_2_368000_4306000_image.tif'  
        SERC_RGBcam_array, SERC_RGBcam_metadata = RGBraster2array(RGB_geotif)
```

```
In [5]: SERC_RGBcam_array.shape
```

```
Out [5]: (10000, 10000, 3)
```

```
In [6]: #Display information stored in header
        for key in sorted(SERC_RGBcam_metadata.keys()):
            print(key)
```

```
array_cols
array_rows
bands
driver
ext_dict
extent
geotransform
noDataValue
pixelHeight
pixelWidth
projection
scaleFactor
```

```
In [7]: def plot_band_array(band_array,
                             refl_extent,
                             colorlimit,
                             ax=plt.gca(),
                             title='',
                             cbar = 'on',
                             cmap_title='',
                             colormap='spectral'):
```

*'''plot\_band\_array reads in and plots a single band or an rgb band combination of*

*-----*

*Parameters*

*-----*

*band\_array: flightline array of reflectance values, created from h5refl2array*  
*refl\_extent: extent of reflectance data to be plotted (xMin, xMax, yMin, yMax)*  
*colorlimit: range of values to plot (min,max). Best to look at the histogram of*  
*ax: optional, default = current axis*  
*title: string, optional; plot title*  
*cmap\_title: string, optional; colorbar title*  
*colormap: string, optional; see <https://matplotlib.org/examples/color/colormap>*

*-----*

*Returns*

*plots array of single band or RGB if given a 3-band*

*-----*


*Example:*

*-----*


```
plot_band_array(SERC_RGBcam_array,
                 SERC_RGBcam_metadata['extent'],
                 (1,255),
                 title='SERC RGB Camera Tile',
```

```
cbar='off')'''
```

```
plot = plt.imshow(band_array,extent=refl_extent,clim=colorlimit);  
if cbar == 'on':  
    cbar = plt.colorbar(plot,aspect=40); plt.set_cmap(colormap);  
    cbar.set_label(cmap_title,rotation=90,labelpad=20)  
plt.title(title); ax = plt.gca();  
ax.ticklabel_format(useOffset=False, style='plain'); #do not use scientific notation  
rotatexlabels = plt.setp(ax.get_xticklabels(),rotation=90); #rotate x tick labels
```




```
In [8]: plot_band_array(SERC_RGBcam_array,  
                        SERC_RGBcam_metadata['extent'],  
                        (1,255),  
                        title='SERC RGB Camera Tile',  
                        cbar='off')
```



```
In [10]: plt.hist(np.ravel(SERC_RGBcam_array[:, :, 0]), 20);  
         plt.title('Histogram of SERC Camera Red Band')  
         plt.xlabel('Brightness'); plt.ylabel('Frequency')
```


```
Out[10]: Text(0, 0.5, 'Frequency')
```



1. Plot histograms of the green and blue bands.


```
In [12]: # Histogram of green band
plt.hist(np.ravel(SERC_RGBcam_array[:, :, 1]), 20);
plt.title('Histogram of SERC Camera Green Band')
plt.xlabel('Brightness'); plt.ylabel('Frequency')
```

```
Out[12]: Text(0, 0.5, 'Frequency')
```



```
In [13]: # Histogram of blue band
plt.hist(np.ravel(SERC_RGBcam_array[:, :, 2]), 20);
plt.title('Histogram of SERC Camera Blue Band')
plt.xlabel('Brightness'); plt.ylabel('Frequency')
```

```
Out[13]: Text(0, 0.5, 'Frequency')
```



## 2. Explore the data

```
In [18]: # Determine the minimum and maximum reflectance for each band.
# Print these values with a print statement.
# HINT: Use the numpy functions np.amin() and np.amax()

# red
print('Min reflectance in red band: ', str(np.amin(np.ravel(SERC_RGBcam_array[:,:,:0])))
print('Max reflectance in red band: ', str(np.amax(np.ravel(SERC_RGBcam_array[:,:,:0])))

# green
print('Min reflectance in green band: ', str(np.amin(np.ravel(SERC_RGBcam_array[:,:,:1])))
print('Max reflectance in green band: ', str(np.amax(np.ravel(SERC_RGBcam_array[:,:,:1])))

# blue
print('Min reflectance in blue band: ', str(np.amin(np.ravel(SERC_RGBcam_array[:,:,:2])))
print('Max reflectance in blue band: ', str(np.amax(np.ravel(SERC_RGBcam_array[:,:,:2])))
```

Min reflectance in red band: 21  
Max reflectance in red band: 255  
Min reflectance in green band: 5  
Max reflectance in green band: 255  
Min reflectance in blue band: 12  
Max reflectance in blue band: 255



```
In [22]: # b. What UTM zone is this data in?
# Hint: Print out SERC_RGBcam_metadata['projection']

print(SERC_RGBcam_metadata['projection'])
```


```
PROJCS["WGS 84 / UTM zone 18N",GEOGCS["WGS 84",DATUM["WGS_1984",SPHEROID["WGS 84",6378137,298.257242571,0,0,0,0],PRIMAR
```

b. This data is in UTM zone 18N


```
In [26]: # c. Use the plot_band_array function to plot each band of the camera image separately.
# HINT: Use splicing to extract each band (e.g., SERC_RGBcam_array[:, :, 0]).
```

```
red = SERC_RGBcam_array[:, :, 0]
green = SERC_RGBcam_array[:, :, 1]
blue = SERC_RGBcam_array[:, :, 2]

plot_band_array(red,
                 SERC_RGBcam_metadata['extent'],
                 (1, 255),
                 title='SERC RGB Camera Tile: Red',
                 cbar='off')
```



```
In [27]: plot_band_array(green,
                        SERC_RGBcam_metadata['extent'],
                        (1,255),
                        title='SERC RGB Camera Tile: Green',
                        cbar='off')
```



```
In [28]: plot_band_array(blue,
                        SERC_RGBcam_metadata['extent'],
                        (1,255),
                        title='SERC RGB Camera Tile: Blue',
                        cbar='off')
```

