

# Bruns-Nicholas\_RGB-notebooks

July 5, 2018

\*This 3rd and final activity before heading to Boulder works with a tile of AOP RGB data. Success with a couple test tasks will suggest I have correctly set up my machine and have entry level comfort working with Jupyter notebooks.

## 1 Setup and environment loading

```
In [5]: import sys
        sys.version
```

```
Out[5]: '3.5.5 |Anaconda, Inc.| (default, Apr 26 2018, 08:11:22) \n[GCC 4.2.1 Compatible Clang 4
```

```
In [12]: import gdal
         import numpy as np
         import matplotlib.pyplot as plt
         %matplotlib inline
         import warnings
         warnings.filterwarnings('ignore')
```

## 2 Define a read-in function

```
In [13]: def RGBraster2array(RGB_geotif):
         """RGBraster2array reads in a NEON AOP geotif file and returns
         a numpy array, and header containing associated metadata with spatial information.
         -----
         Parameters
             RGB_geotif -- full or relative path and name of reflectance hdf5 file
         -----
         Returns
         -----
         array:
             numpy array of geotif values
         metadata:
             dictionary containing the following metadata (all strings):
                 array_rows
                 array_cols
                 bands
                 driver
```

```

        projection
        geotransform
        pixelWidth
        pixelHeight
        extent
        noDataValue
        scaleFactor
    -----
    Example Execution:
    -----
    RGB_geotif = '2017_SERC_2_368000_4306000_image.tif'
    RGBcam_array, RGBcam_metadata = RGBraster2array(RGB_geotif) """

    metadata = {}
    dataset = gdal.Open(RGB_geotif)
    metadata['array_rows'] = dataset.RasterYSize
    metadata['array_cols'] = dataset.RasterXSize
    metadata['bands'] = dataset.RasterCount
    metadata['driver'] = dataset.GetDriver().LongName
    metadata['projection'] = dataset.GetProjection()
    metadata['geotransform'] = dataset.GetGeoTransform()

    mapinfo = dataset.GetGeoTransform()
    metadata['pixelWidth'] = mapinfo[1]
    metadata['pixelHeight'] = mapinfo[5]

    metadata['ext_dict'] = {}
    metadata['ext_dict']['xMin'] = mapinfo[0]
    metadata['ext_dict']['xMax'] = mapinfo[0] + dataset.RasterXSize/mapinfo[1]
    metadata['ext_dict']['yMin'] = mapinfo[3] + dataset.RasterYSize/mapinfo[5]
    metadata['ext_dict']['yMax'] = mapinfo[3]

    metadata['extent'] = (metadata['ext_dict']['xMin'], metadata['ext_dict']['xMax'],
                        metadata['ext_dict']['yMin'], metadata['ext_dict']['yMax'])

    raster = dataset.GetRasterBand(1)
    array_shape = raster.ReadAsArray(0,0,metadata['array_cols'],metadata['array_rows'])
    metadata['noDataValue'] = raster.GetNoDataValue()
    metadata['scaleFactor'] = raster.GetScale()

    array = np.zeros((array_shape[0],array_shape[1],dataset.RasterCount),'uint8') #pre-
    for i in range(1, dataset.RasterCount+1):
        band = dataset.GetRasterBand(i).ReadAsArray(0,0,metadata['array_cols'],metadata['array_rows'])
        band[band==metadata['noDataValue']] = np.nan
        band = band/metadata['scaleFactor']
        array[...,i-1] = band

    return array, metadata

```

### 3 Load data

```
In [15]: RGB_geotif='./data/2017_SERC_2_368000_4306000_image.tif'
        SERC_RGBcam_array, SERC_RGBcan_metadata = RGBBraster2array(RGB_geotif)
```

#### 3.1 check that it worked!

```
In [17]: SERC_RGBcam_array.shape
```

```
Out[17]: (10000, 10000, 3)
```

```
In [21]: for key in sorted(SERC_RGBcan_metadata.keys()):
        print(key)
```

```
array_cols
array_rows
bands
driver
ext_dict
extent
geotransform
noDataValue
pixelHeight
pixelWidth
projection
scaleFactor
```

### 4 Define a plot function

```
In [103]: def plot_band_array(band_array,
                             refl_extent,
                             colorlimit,
                             ax=plt.gca(),
                             title='',
                             cbar='on',
                             cmap_title='',
                             colormap='spectral'):
```

```
'''plot_band_array reads in and plots a single band or an rgb band combination of
-----
```

```
Parameters
```

```
-----
```


```
band_array: flightline array of reflectance values, created from h5refl2array
refl_extent: extent of reflectance data to be plotted (xMin, xMax, yMin, yMax)
colorlimit: range of values to plot (min,max). Best to look at the histogram o
ax: optional, default = current axis
title: string, optional; plot title
```

```

    cmap_title: string, optional; colorbar title
    colormap: string, optional; see https://matplotlib.org/examples/color/colormap
-----
Returns
    plots array of single band or RGB if given a 3-band
-----
Example:
-----
plot_band_array(SERC_RGBcam_array,
                SERC_RGBcam_metadata['extent'],
                (1,255),
                title='SERC RGB Camera Tile',
                cbar='off')'''


plot = plt.imshow(band_array,extent=refl_extent,clim=colorlimit);
if cbar == 'on':
    cbar = plt.colorbar(plot,aspect=40); plt.set_cmap(colormap);
    cbar.set_label(cmap_title,rotation=90,labelpad=20)
plt.title(title); ax = plt.gca();
ax.ticklabel_format(useOffset=False, style='plain'); #do not use scientific notation
rotatexlabels = plt.setp(ax.get_xticklabels(),rotation=90); #rotate x tick labels

```




## 5 Render RGB image and plot histograms

```
In [71]: plot_band_array(SERC_RGBcam_array,  
                        SERC_RGBcam_metadata['extent'],  
                        (5,255),  
                        title='SERC RGB Camera Tile',  
                        cbar='off')
```




```
In [28]: plt.hist(np.ravel(SERC_RGBcam_array[:, :, 0]), 20, facecolor='r');  
plt.title('Histogram of SERC Camera Red Band')  
plt.xlabel('Brightness'); plt.ylabel('Frequency')
```

```
Out [28]: Text(0,0.5, 'Frequency')
```




```
In [29]: plt.hist(np.ravel(SERC_RGBcam_array[:, :, 1]), 20, facecolor='g');  
plt.title('Histogram of SERC Camera Green Band')  
plt.xlabel('Brightness'); plt.ylabel('Frequency')
```

```
Out[29]: Text(0, 0.5, 'Frequency')
```



```
In [30]: plt.hist(np.ravel(SERC_RGBcam_array[:, :, 2]), 20, facecolor='b');  
plt.title('Histogram of SERC Camera Blue Band')  
plt.xlabel('Brightness'); plt.ylabel('Frequency')
```

```
Out[30]: Text(0, 0.5, 'Frequency')
```



## 6 Extract reflectance range for each band

```
In [88]: rmin=np.amin(SERC_RGBcam_array[:, :, 0])
         rmax=np.amax(SERC_RGBcam_array[:, :, 0])
         print( "red: " + str(rmin) + " - " + str(rmax))
```

red: 21 - 255

```
In [90]: gmin=str(np.amin(SERC_RGBcam_array[:, :, 1]))
         gmax=str(np.amax(SERC_RGBcam_array[:, :, 1]))
         print( "green: " + str(gmin) + " - " + str(gmax))
```

green: 5 - 255

```
In [91]: bmin=np.amin(SERC_RGBcam_array[:, :, 2])
         bmax=np.amax(SERC_RGBcam_array[:, :, 2])
         print( "blue: " + str(bmin) + " - " + str(bmax))
```

blue: 12 - 255




## 7 Extract UTM zone from meta data

```
In [64]: SERC_RGBcam_metadata['projection'].split()[5].split(',')[0]
```


```
Out[64]: '18N'
```

## 8 Plot single color channels

```
In [99]: plot_band_array(SERC_RGBcam_array[:, :, 0],  
                        SERC_RGBcam_metadata['extent'],  
                        (rmin, rmax),  
                        title='Red channel plot',  
                        cbar='on', colormap='Reds')
```



```
In [100]: plot_band_array(SERC_RGBcam_array[:, :, 1],  
                          SERC_RGBcam_metadata['extent'],  
                          (rmin, rmax),  
                          title='Green channel plot',  
                          cbar='on', colormap='Greens')
```



```
In [102]: plot_band_array(SERC_RGBcam_array[:, :, 2],  
                           SERC_RGBcam_metadata['extent'],  
                           (rmin, rmax),  
                           title='Green channel plot',  
                           cbar='on', colormap='Blues')
```

