

lahmed_jupyter_exercise

July 5, 2018

0.1 ## Week 3: Documentation with Jupyter Notebooks

Labeeb Ahmed

```
In [71]: # import modules
import sys
import gdal
import numpy as np
import matplotlib.pyplot as plt
%matplotlib inline
import warnings
warnings.filterwarnings('ignore')

# check versions
sys.version # confirm running python 3.5.x
gdal.VersionInfo()
```

```
Out[71]: '2020200'
```

RGBraster2array() function can read and convert raster images to numpy array

```
In [72]: def RGBraster2array(RGB_geotif):
        """RGBraster2array reads in a NEON AOP geotif file and returns
        a numpy array, and header containing associated metadata with spatial information
        -----
        Parameters
            RGB_geotif -- full or relative path and name of reflectance hdf5 file
        -----
        Returns
        -----
        array:
            numpy array of geotif values
        metadata:
            dictionary containing the following metadata (all strings):
                array_rows
                array_cols
                bands
                driver
```

```

        projection
        geotransform
        pixelWidth
        pixelHeight
        extent
        noDataValue
        scaleFactor
    """
    -----
    Example Execution:
    -----
    RGB_geotif = '2017_SERC_2_368000_4306000_image.tif'
    RGBcam_array, RGBcam_metadata = RGBraster2array(RGB_geotif) """

    metadata = {}
    dataset = gdal.Open(RGB_geotif)
    metadata['array_rows'] = dataset.RasterYSize
    metadata['array_cols'] = dataset.RasterXSize
    metadata['bands'] = dataset.RasterCount
    metadata['driver'] = dataset.GetDriver().LongName
    metadata['projection'] = dataset.GetProjection()
    metadata['geotransform'] = dataset.GetGeoTransform()

    mapinfo = dataset.GetGeoTransform()
    metadata['pixelWidth'] = mapinfo[1]
    metadata['pixelHeight'] = mapinfo[5]

    metadata['ext_dict'] = {}
    metadata['ext_dict']['xMin'] = mapinfo[0]
    metadata['ext_dict']['xMax'] = mapinfo[0] + dataset.RasterXSize/mapinfo[1]
    metadata['ext_dict']['yMin'] = mapinfo[3] + dataset.RasterYSize/mapinfo[5]
    metadata['ext_dict']['yMax'] = mapinfo[3]

    metadata['extent'] = (metadata['ext_dict']['xMin'], metadata['ext_dict']['xMax'],
                        metadata['ext_dict']['yMin'], metadata['ext_dict']['yMax'])

    raster = dataset.GetRasterBand(1)
    array_shape = raster.ReadAsArray(0,0,metadata['array_cols'],metadata['array_rows'])
    metadata['noDataValue'] = raster.GetNoDataValue()
    metadata['scaleFactor'] = raster.GetScale()

    array = np.zeros((array_shape[0],array_shape[1],dataset.RasterCount),'uint8') #pr
    for i in range(1, dataset.RasterCount+1):
        band = dataset.GetRasterBand(i).ReadAsArray(0,0,metadata['array_cols'],metada
        band[band==metadata['noDataValue']] = np.nan
        band = band/metadata['scaleFactor']
        array[...,i-1] = band

    return array, metadata

```

0.1.1 Define RGB_geotif path and run RGBraster2array()

```
In [73]: RGB_geotif = 'C:/Users/CBPStaff/Neon_Data/2017_SERC_2_368000_4306000_image.tif'
        SERC_RGBcam_array, SERC_RGBcam_metadata = RGBraster2array(RGB_geotif)
```

```
SERC_RGBcam_array.shape # print array dim
```

```
Out[73]: (10000, 10000, 3)
```

```
In [74]: print (sorted(SERC_RGBcam_metadata.keys())) #Print array metadata keys
```

```
['array_cols', 'array_rows', 'bands', 'driver', 'ext_dict', 'extent', 'geotransform', 'noDataV
```

0.1.2 Plotting RGB Camera Image

Using plot_band_array(), we'll plot the array data

```
In [75]: def plot_band_array(band_array,
                             refl_extent,
                             colorlimit,
                             ax=plt.gca(),
                             title='',
                             cbar='on',
                             cmap_title='',
                             colormap='spectral'):
```

```
'''plot_band_array reads in and plots a single band or an rgb band combination of
-----
```

```
Parameters
-----
```

```
band_array: flightline array of reflectance values, created from h5refl2array
refl_extent: extent of reflectance data to be plotted (xMin, xMax, yMin, yMax)
colorlimit: range of values to plot (min,max). Best to look at the histogram
ax: optional, default = current axis
title: string, optional; plot title
cmap_title: string, optional; colorbar title
colormap: string, optional; see https://matplotlib.org/examples/color/colormaps
-----
```

```
Returns
```

```
plots array of single band or RGB if given a 3-band
-----
```


```
Example:
-----
```

```
plot_band_array(SERC_RGBcam_array,
                SERC_RGBcam_metadata['extent'],
                (1,255),
                title='SERC RGB Camera Tile',
                cbar='off')'''
```

```

plot = plt.imshow(band_array,extent=refl_extent,clim=colorlimit);
if cbar == 'on':
    cbar = plt.colorbar(plot,aspect=40); plt.set_cmap(colormap);
    cbar.set_label(cmap_title,rotation=90,labelpad=20)
plt.title(title); ax = plt.gca();
ax.ticklabel_format(useOffset=False, style='plain'); #do not use scientific notation
rotatexlabels = plt.setp(ax.get_xticklabels(),rotation=90); #rotate x tick labels


```



```

In [78]: # display the array
plot_band_array(SERC_RGBcam_array,
                SERC_RGBcam_metadata['extent'],
                (1,255),
                title='SERC RGB Camera Tile',
                cbar='off')

```




0.1.3 Plot histogram of red band

```
In [84]: # plot the histogram
        """ Note:[:, :, 0] is band 1 or red,
              [:, :, 1] is band 2 or blue and etc"""

        plt.hist(np.ravel(SERC_RGBcam_array[:, :, 0]), 20, color='red');
        plt.title('Histogram of SERC Camera Red Band')
        plt.xlabel('Brightness'); plt.ylabel('Frequency')
```

```
Out[84]: Text(0,0.5,'Frequency')
```




0.2 # Challenge Exercises

(1) Plot histograms of green and blue bands


```
In [85]: # Plot green band
plt.hist(np.ravel(SERC_RGBcam_array[:, :, 1]), 20, color='green');
plt.title('Histogram of SERC Camera Red Band')
plt.xlabel('Brightness'); plt.ylabel('Frequency')
```

```
Out[85]: Text(0,0.5,'Frequency')
```



```
In [86]: # Plot blue band
plt.hist(np.ravel(SERC_RGBcam_array[:, :, 2]), 20, color='blue');
plt.title('Histogram of SERC Camera Blue Band')
plt.xlabel('Brightness'); plt.ylabel('Frequency')
```

```
Out[86]: Text(0,0.5,'Frequency')
```



(2) Data exploration

```
In [106]: # (a) get array min & max values
```

```
def get_mn_mx(array, band):
```

```
a = np.ravel(array[:, :, band])
```

```
return np.amin(a), np.amax(a)
```

```
for band in range(3):
```

```
mn, mx = get_mn_mx(SERC_RGBcam_array, band)
```

```
print ("Band #{}: min={}; max={}".format(band, mn, mx))
```

```
# (b) raster projection
```

```
SERC_RGBcam_metadata['projection']
```

Band #0: min=21; max=255

Band #1: min=5; max=255

Band #2: min=12; max=255

```
Out[106]: 'PROJCS["WGS 84 / UTM zone 18N",GEOGCS["WGS 84",DATUM["WGS_1984",SPHEROID["WGS 84",63
```


In [108]: # (c) `plot_band_array` to plot all three bands separately

Red band


```

plot_band_array(SERC_RGBcam_array[:, :, 0],
                SERC_RGBcam_metadata['extent'],
                (1, 255),
                title='SERC Red Band Camera Tile',
                cbar='off')


```



```

In [109]: # Green band
plot_band_array(SERC_RGBcam_array[:, :, 1],
                SERC_RGBcam_metadata['extent'],
                (1, 255),
                title='SERC Green Band Camera Tile',
                cbar='off')

```



```
In [110]: # Blue band
plot_band_array(SERC_RGBcam_array[:, :, 2],
                SERC_RGBcam_metadata['extent'],
                (1, 255),
                title='SERC Blue Band Camera Tile',
                cbar='off')
```

