

TB_rgbNotebook

June 29, 2018

0.1 NeonScience Data Science workshop

0.2 Preinstitute Week 3

0.3 Reading RGB files in PYthon

0.3.1 Tim Bailey

```
In [1]: import sys
        sys.version
```

```
Out[1]: '3.5.5 |Anaconda custom (64-bit)| (default, May 13 2018, 21:12:35) \n[GCC 7.2.0]'
```

I had some problems with this step In the setup instructions earlier in the workshop two commands were omitted for installing the python 3.5 version. Luckily they were there for the windows and mac versions

```
conda create -n p35 python=3.5 anaconda
source activate p35
```

```
In [2]: #import gdal
        import gdal, osr

        #not entirely sure what osr does
```

imports gdal library to open geospatial files

```
In [3]: import numpy as np
        import matplotlib.pyplot as plt
        %matplotlib inline
        import warnings
        warnings.filterwarnings('ignore')
        #unsure what the % operator does
```

Imports Numpy library for later use Numpy is a python library for doing math on arrays

```
In [4]: def RGBraster2array(RGB_geotif):
        """RGBraster2array reads in a NEON AOP geotif file and returns
        a numpy array, and header containing associated metadata with spatial information.
        -----
        Parameters
```

```

    RGB_geotif -- full or relative path and name of reflectance hdf5 file
-----
Returns
-----
array:
    numpy array of geotif values
metadata:
    dictionary containing the following metadata (all strings):
        array_rows
        array_cols
        bands
        driver
        projection
        geotransform
        pixelWidth
        pixelHeight
        extent
        noDataValue
        scaleFactor
-----
Example Execution:
-----

RGB_geotif = '2017_SERC_2_368000_4306000_image.tif'
RGBcam_array, RGBcam_metadata = RGBraster2array(RGB_geotif) """

metadata = {}
dataset = gdal.Open(RGB_geotif)
# dataset calls gdal function open and applies it the the file variable RGB_geotif
metadata['array_rows'] = dataset.RasterYSize
metadata['array_cols'] = dataset.RasterXSize
metadata['bands'] = dataset.RasterCount
metadata['driver'] = dataset.GetDriver().LongName
metadata['projection'] = dataset.GetProjection()
metadata['geotransform'] = dataset.GetGeoTransform()
# extracts metadata values from geotif header and assigns values to internal variables

mapinfo = dataset.GetGeoTransform()
metadata['pixelWidth'] = mapinfo[1]
metadata['pixelHeight'] = mapinfo[5]

metadata['ext_dict'] = {}
metadata['ext_dict']['xMin'] = mapinfo[0]
metadata['ext_dict']['xMax'] = mapinfo[0] + dataset.RasterXSize/mapinfo[1]
metadata['ext_dict']['yMin'] = mapinfo[3] + dataset.RasterYSize/mapinfo[5]
metadata['ext_dict']['yMax'] = mapinfo[3]
# extracts Max and Minimum coordinates from geotif metadata
metadata['extent'] = (metadata['ext_dict']['xMin'], metadata['ext_dict']['xMax'],
                    metadata['ext_dict']['yMin'], metadata['ext_dict']['yMax'])

```

```

raster = dataset.GetRasterBand(1)
array_shape = raster.ReadAsArray(0,0,metadata['array_cols'],metadata['array_rows'])
metadata['noDataValue'] = raster.GetNoDataValue()
metadata['scaleFactor'] = raster.GetScale()

array = np.zeros((array_shape[0],array_shape[1],dataset.RasterCount),'uint8') #pre
for i in range(1, dataset.RasterCount+1):
    band = dataset.GetRasterBand(i).ReadAsArray(0,0,metadata['array_cols'],metadata
    band[band==metadata['noDataValue']]=np.nan
    band = band/metadata['scaleFactor']
    array[...,i-1] = band

return array, metadata

```

I actually had problems with the previous cell I cut and paste from the workshop instruction manual in split screen I was ending up getting key errors on 'ext_dict' variable that I believe were the result of copy and paste errors related to the cut and paste function I am using Ubuntu 18.04 for this project

```

In [5]: RGB_geotif = './2017_SERC_2_368000_4306000_image.tif'
        #assigns RGB_geotif variable to a specific file
        SERC_RGBcam_array, SERC_RGBcam_metadata = RGBBraster2array(RGB_geotif)
        #builds array and populates internal metadata using the preceeding function

        # it would probably be useful to change the file to a variable that could assigned

In [6]: SERC_RGBcam_array.shape
        # returns the dimensions of the array

Out[6]: (10000, 10000, 3)

In [7]: for key in sorted(SERC_RGBcam_metadata.keys()):
        print(key)
        # assigns the metadata
        # prints metadata variables

array_cols
array_rows
bands
driver
ext_dict
extent
geotransform
noDataValue
pixelHeight
pixelWidth
projection
scaleFactor

```

```

In [8]: def plot_band_array(band_array,
                             refl_extent,
                             colorlimit,
                             ax=plt.gca(),
                             title='',
                             cbar='on',
                             cmap_title='',
                             colormap='spectral'):


    '''plot_band_array reads in and plots a single band or an rgb band combination of
    -----
    Parameters
    -----
        band_array: flightline array of reflectance values, created from h5refl2array
        refl_extent: extent of reflectance data to be plotted (xMin, xMax, yMin, yMax)
        colorlimit: range of values to plot (min,max). Best to look at the histogram of
        ax: optional, default = current axis
        title: string, optional; plot title
        cmap_title: string, optional; colorbar title
        colormap: string, optional; see https://matplotlib.org/examples/color/colormap

    -----
    Returns
        plots array of single band or RGB if given a 3-band

    -----
    Example:
    -----
        plot_band_array(SERC_RGBcam_array,
                        SERC_RGBcam_metadata['extent'],
                        (1,255),
                        title='SERC RGB Camera Tile',
                        cbar='off')'''


    plot = plt.imshow(band_array,extent=refl_extent,clim=colorlimit);
    if cbar == 'on':
        cbar = plt.colorbar(plot,aspect=40); plt.set_cmap(colormap);
        cbar.set_label(cmap_title,rotation=90,labelpad=20)
    plt.title(title); ax = plt.gca();
    ax.ticklabel_format(useOffset=False, style='plain'); #do not use scientific notation
    rotatexlabels = plt.setp(ax.get_xticklabels(),rotation=90); #rotate x tick labels

```



The preceeding cell defines a plotting function


```
In [9]: plot_band_array(SERC_RGBcam_array,  
                        SERC_RGBcam_metadata['extent'],  
                        (1,255),  
                        title='SERC RGB Camera Tile',  
                        cbar='off')
```



The preceeding cell plots the output of the Serc_RGBcam_array

```
In [10]: plt.hist(np.ravel(SERC_RGBcam_array[:, :, 0]), 20);  
         plt.title('Histogram of SERC Camera Red Band')  
         plt.xlabel('Brightness'); plt.ylabel('Frequency')
```

```
Out[10]: Text(0, 0.5, 'Frequency')
```




```
In [11]: # Red band above'''
```

```
In [12]: # Green band'''
```


```
plt.hist(np.ravel(SERC_RGBcam_array[:,0,:]),20);  
plt.title('Histogram of SERC Camera Green Band')  
plt.xlabel('Brightness'); plt.ylabel('Frequency')
```

```
Out[12]: Text(0,0.5,'Frequency')
```




```
In [13]: # Blue band'''  
plt.hist(np.ravel(SERC_RGBcam_array[0,:,:],20);  
plt.title('Histogram of SERC Camera Blue Band')  
plt.xlabel('Brightness'); plt.ylabel('Frequency')
```

```
Out[13]: Text(0,0.5,'Frequency')
```

```
In [14]: # all bands
plt.hist(np.ravel(SERC_RGBcam_array[:, :, :]), 20);
plt.title('Histogram of SERC Camera all Band')
plt.xlabel('Brightness'); plt.ylabel('Frequency')
```

```
Out[14]: Text(0,0.5,'Frequency')
```



```
In [15]: SERC_RGBcam_metadata['projection']
```

```
Out[15]: 'PROJCS["WGS 84 / UTM zone 18N",GEOGCS["WGS 84",DATUM["WGS_1984",SPHEROID["WGS 84",63
```

```
In [16]: # Projection UTM zone 18N wgs 84
```

```
In [17]: r = np.array(SERC_RGBcam_array[:, :, 0])
np.mean(r)
# calculate the mean of the red band using np statistical commands
```

```
Out[17]: 173.56908259
```

```
In [18]: b = np.array(SERC_RGBcam_array[0, :, :])
# assign blue band to the array
np.mean(b)
# evaluate the mean of the array b
```

```
Out[18]: 168.21766666666667
```

```
In [19]: g = np.array(SERC_RGBcam_array[:, 0, :])
np.median(g)
# assign array
# evaluate the median of the green band
```

```
Out[19]: 164.0
```



```

~/anaconda3/envs/p35/lib/python3.5/site-packages/matplotlib/pyplot.py in hist(x, bins,
3130             histtype=histtype, align=align, orientation=orientation,
3131             rwidth=rwidth, log=log, color=color, label=label,
-> 3132             stacked=stacked, normed=normed, data=data, **kwargs)
3133     finally:
3134         ax._hold = washold

~/anaconda3/envs/p35/lib/python3.5/site-packages/matplotlib/__init__.py in inner(ax, *
1853         "the Matplotlib list!)" % (label_namer, func.__name__),
1854         RuntimeWarning, stacklevel=2)
-> 1855     return func(ax, *args, **kwargs)
1856
1857     inner.__doc__ = _add_data_doc(inner.__doc__,


~/anaconda3/envs/p35/lib/python3.5/site-packages/matplotlib/axes/_axes.py in hist(**f
6528         # this will automatically overwrite bins,
6529         # so that each histogram uses the same bins
-> 6530         m, bins = np.histogram(x[i], bins, weights=w[i], **hist_kwargs)
6531         m = m.astype(float) # causes problems later if it's an int
6532         if mlast is None:

~/anaconda3/envs/p35/lib/python3.5/site-packages/numpy/lib/function_base.py in histogr
816         if weights is None:
817             for i in arange(0, len(a), BLOCK):
--> 818                 sa = sort(a[i:i+BLOCK])
819                 cum_n += np.r_[sa.searchsorted(bin_edges[:-1], 'left'),
820                               sa.searchsorted(bin_edges[-1], 'right')]

~/anaconda3/envs/p35/lib/python3.5/site-packages/numpy/core/fromnumeric.py in sort(a, a
845     else:
846         a = asanyarray(a).copy(order="K")
--> 847         a.sort(axis=axis, kind=kind, order=order)
848         return a
849

```

KeyboardInterrupt:



1 Plotted histogram above without the ravel function to bin to 20 unit

2 it definitely takes a lot longer.

```
In [25]: np.amin(b)  
         #minimum blue value'''
```

```
Out[25]: 50
```

```
In [26]: np.amax(b)  
         #maximum blue value'''
```

```
Out[26]: 255
```

```
In [27]: np.amin(g)  
         # minimum green value'''
```

```
Out[27]: 55
```

```
In [28]: np.amax(g)  
         # maximum green value'''
```

```
Out[28]: 255
```

```
In [29]: np.amin(r)  
         # min red'''
```

Out[29]: 21

```
In [30]: np.amax(r)
         #max red value'''
```

Out[30]: 255

2.1 Review of histograms