

Step 1: Import libraries

In [1]:

```
import sys, gdal, re
import numpy as np
import matplotlib.pyplot as plt
%matplotlib inline
import warnings
warnings.filterwarnings('ignore')
```

Step 2: Define the function to convert RGB rasters to arrays (RGBraster2array)

This function reads in a NEON AOP geotiff file and returns a numpy array, and an header that contains associated metadata with spatial information.

Parameters:

RGB_geotif -- full or relative path and name of reflectance hdf5 file

Returns:

array: numpy array of geotif values

metadata: dictionary containing the following metadata (all strings):

- array_rows
- array_cols
- bands
- driver
- projection
- geotransform
- pixelWidth
- pixelHeight
- extent
- noDataValue
- scaleFactor

Example of execution:

```
RGB_geotif = '2017_SERC_2_368000_4306000_image.tif'
RGBcam_array, RGBcam_metadata = RGBraster2array(RGB_geotif)
```

In [2]:

```
def RGBraster2array(RGB_geotif):
    metadata = {}
    dataset = gdal.Open(RGB_geotif)
    metadata['array_rows'] = dataset.RasterYSize
    metadata['array_cols'] = dataset.RasterXSize
    metadata['bands'] = dataset.RasterCount
    metadata['driver'] = dataset.GetDriver().LongName
    metadata['projection'] = dataset.GetProjection()
    metadata['geotransform'] = dataset.GetGeoTransform()

    mapinfo = dataset.GetGeoTransform()
    metadata['pixelWidth'] = mapinfo[1]
    metadata['pixelHeight'] = mapinfo[5]

    metadata['ext_dict'] = {}
    metadata['ext_dict']['xMin'] = mapinfo[0]
    metadata['ext_dict']['xMax'] = mapinfo[0] + dataset.RasterXSize/mapinfo[1]
    metadata['ext_dict']['yMin'] = mapinfo[3] + dataset.RasterYSize/mapinfo[5]
    metadata['ext_dict']['yMax'] = mapinfo[3]

    metadata['extent'] = (metadata['ext_dict']['xMin'],metadata['ext_dict']['xMa
x'],
                        metadata['ext_dict']['yMin'],metadata['ext_dict']['yMa
x'])

    raster = dataset.GetRasterBand(1)
    array_shape = raster.ReadAsArray(0,0,metadata['array_cols'],metadata['array_
rows']).astype(np.float).shape
    metadata['noDataValue'] = raster.GetNoDataValue()
    metadata['scaleFactor'] = raster.GetScale()

    array = np.zeros((array_shape[0],array_shape[1],dataset.RasterCount),'uint8'
) #pre-allocate stackedArray matrix
    for i in range(1, dataset.RasterCount+1):
        band = dataset.GetRasterBand(i).ReadAsArray(0,0,metadata['array_cols'],m
etadata['array_rows']).astype(np.float)
        band[band==metadata['noDataValue']] = np.nan
        band = band/metadata['scaleFactor']
        array[...,i-1] = band

    return array, metadata
```

Step 3: Define the RGB image to read

In [3]:

```
RGB_geotif = './2017_SERC_2_368000_4306000_image.tif'
```

Step 4: Run the function (RGBraster2array) to extract the array and metadata from RGB image.

In [4]:

```
SERC_RGBcam_array, SERC_RGBcam_metadata = RGBBraster2array(RGB_geotif)
```

Step 5: Display the information stored in header

In [5]:

```
for key in sorted(SERC_RGBcam_metadata.keys()):  
    print(key)
```

```
array_cols  
array_rows  
bands  
driver  
ext_dict  
extent  
geotransform  
noDataValue  
pixelHeight  
pixelWidth  
projection  
scaleFactor
```

Step 6: Define function to plot the array data

plot_band_array reads in and plots a single band or an rgb band combination of a reflectance array

Parameters:

`band_array`: flightline array of reflectance values, created from `h5refl2array` function

`refl_extent`: extent of reflectance data to be plotted (`xMin`, `xMax`, `yMin`, `yMax`) - use `metadata['extent']` from `h5refl2array` function

`colorlimit`: range of values to plot (`min`, `max`). Best to look at the histogram of reflectance values before plotting to determine `colorlimit`.

`ax`: optional, default = current axis

`title`: string, optional; plot title

`cmap_title`: string, optional; colorbar title

`colormap`: string, optional; see https://matplotlib.org/examples/color/colormaps_reference.html for list of colormaps

Returns:

plots array of single band or RGB if given a 3-band


Example:

```
plot_band_array(SERC_RGBcam_array, SERC_RGBcam_metadata['extent'], (1,255), title='SERC RGB  
Camera Tile', cbar='off')
```

In [6]:

```
def plot_band_array(band_array,
                    refl_extent,
                    colorlimit,
                    ax=plt.gca(),
                    title='',
                    cbar='on',
                    cmap_title='',
                    colormap='spectral'):


    plot = plt.imshow(band_array,extent=refl_extent,clim=colorlimit);
    if cbar == 'on':
        cbar = plt.colorbar(plot,aspect=40); plt.set_cmap(colormap);
        cbar.set_label(cmap_title,rotation=90,labelpad=20)
    plt.title(title); ax = plt.gca();
    ax.ticklabel_format(useOffset=False, style='plain'); #do not use scientific notation #
    rotatexlabels = plt.setp(ax.get_xticklabels(),rotation=90); #rotate x tick labels 90 degrees
```



Step 7: Plot the array data from the RGB image defined earlier

In [7]:

```
plot_band_array(SERC_RGBcam_array, SERC_RGBcam_metadata['extent'],(1,255), title
='SERC RGB Camera Tile', cbar='off')
```




Step 8: Plot the histogram of the bands (individually and then combined)

In [8]:

```
plt.hist(np.ravel(SERC_RGBcam_array[:, :, 0]), 256);  
plt.title('Histogram of SERC Camera Red Band')  
plt.xlabel('Brightness'); plt.ylabel('Frequency')
```

Out[8]:

Text(0,0.5,'Frequency')




In [9]:

```
plt.hist(np.ravel(SERC_RGBcam_array[:, :, 1]), 256);  
plt.title('Histogram of SERC Camera Green Band')  
plt.xlabel('Brightness'); plt.ylabel('Frequency')
```

Out[9]:

Text(0,0.5, 'Frequency')




In [10]:

```
plt.hist(np.ravel(SERC_RGBcam_array[:, :, 2]), 256);  
plt.title('Histogram of SERC Camera Blue Band')  
plt.xlabel('Brightness'); plt.ylabel('Frequency')
```

Out[10]:

Text(0,0.5, 'Frequency')




In [11]:

```
plt.hist(np.ravel(SERC_RGBcam_array[:, :, 0]), 256);  
plt.title('Histogram of SERC Camera Red Band')  
plt.xlabel('Brightness'); plt.ylabel('Frequency')  
  
plt.hist(np.ravel(SERC_RGBcam_array[:, :, 1]), 256);  
plt.title('Histogram of SERC Camera Green Band')  
plt.xlabel('Brightness'); plt.ylabel('Frequency')  
  
plt.hist(np.ravel(SERC_RGBcam_array[:, :, 2]), 256);  
plt.title('Histogram of SERC Camera Blue Band')  
plt.xlabel('Brightness'); plt.ylabel('Frequency')
```

Out[11]:

Text(0,0.5,'Frequency')



Step 9: Determine the minimum and maximum reflectance for each band

In [12]:

```
for i in range(0,3):
    min = np.amin(SERC_RGBcam_array[:, :, i])
    max = np.amax(SERC_RGBcam_array[:, :, i])
    if i == 0:
        print('-The minimum reflectance for the Red band is '+str(min)+' and its
maximum reflectance is '+str(max)+'.')
    elif i == 1:
        print('-The minimum reflectance for the Green band is '+str(min)+' and i
ts maximum reflectance is '+str(max)+'.')
    elif i == 2:
        print('-The minimum reflectance for the Blue band is '+str(min)+' and it
s maximum reflectance is '+str(max)+'.')

```

-The minimum reflectance for the Red band is 21 and its maximum refl
ectance is 255.

-The minimum reflectance for the Green band is 5 and its maximum ref
lectance is 255.

-The minimum reflectance for the Blue band is 12 and its maximum ref
lectance is 255.

Step 10: Determine the UTM zone of the image

In [13]:

```
try:
    UTMzone = re.search('UTM(.+?)\\'', str(SERC_RGBcam_metadata['projection'])).g
roup(1)
except AttributeError:
    UTMzone = 'UTM Zone not found'

print('The image is in UTM'+ UTMzone + '.')


```

The image is in UTM zone 18N.

Step 11: Plot each band individually


In [14]:

```
plot_band_array(SERC_RGBcam_array[:,:,:0], SERC_RGBcam_metadata['extent'],(1,255), title='SERC Camera Tile - Red Band', cbar='off')
```




In [15]:

```
plot_band_array(SERC_RGBcam_array[:,:,:1], SERC_RGBcam_metadata['extent'],(1,255), title='SERC Camera Tile - Green Band', cbar='off')
```



In [16]:

```
plot_band_array(SERC_RGBcam_array[:, :, 2], SERC_RGBcam_metadata['extent'], (1, 255), title='SERC Camera Tile - Blue Band', cbar='off')
```



THE END. 07/04/2018