

2018_Reading_RGB

July 3, 2018

1 Week 3 Assignment

July 3rd, 2017

Youssef Kaddoura

1.0.1 This Jupyter Notebook show's how to plot NEON RGB camera data

```
In [8]: import numpy as np
import matplotlib.pyplot as plt
%matplotlib inline
import warnings
warnings.filterwarnings('ignore')
```

1.0.2 Defining the Function RGB_Raster to Array

RGBRaster2array reads in a NEON AOP geotif file and returns a numpy array, and header containing associated metadata with spatial information.

```
In [9]: """
-----
Parameters
    RGB_geotif -- full or relative path and name of reflectance hdf5 file*
-----
Returns
-----
array:
    numpy array of geotif values
metadata:
    dictionary containing the following metadata (all strings):
        array_rows
        array_cols
        bands
        driver
        projection
        geotransform
        pixelWidth
        pixelHeight
-----
"""
```

```

        extent
        noDataValue
        scaleFactor """
def RGBraster2array(RGB_geotif):
    metadata = {}
    dataset = gdal.Open(RGB_geotif)
    # I added this line for tracing
    if dataset is None:
        print('dataset is not read properly')
        sys.exit(1)
    metadata['array_rows'] = dataset.RasterYSize
    metadata['array_cols'] = dataset.RasterXSize
    metadata['bands'] = dataset.RasterCount
    metadata['driver'] = dataset.GetDriver().LongName
    metadata['projection'] = dataset.GetProjection()
    metadata['geotransform'] = dataset.GetGeoTransform()

    mapinfo = dataset.GetGeoTransform()
    metadata['pixelWidth'] = mapinfo[1]
    metadata['pixelHeight'] = mapinfo[5]

    metadata['ext_dict'] = {}
    metadata['ext_dict']['xMin'] = mapinfo[0]
    metadata['ext_dict']['xMax'] = mapinfo[0] + dataset.RasterXSize/mapinfo[1]
    metadata['ext_dict']['yMin'] = mapinfo[3] + dataset.RasterYSize/mapinfo[5]
    metadata['ext_dict']['yMax'] = mapinfo[3]

    metadata['extent'] = (metadata['ext_dict']['xMin'], metadata['ext_dict']['xMax'],
                          metadata['ext_dict']['yMin'], metadata['ext_dict']['yMax'])

    raster = dataset.GetRasterBand(1)
    array_shape = raster.ReadAsArray(0,0,metadata['array_cols'],metadata['array_rows'])
    metadata['noDataValue'] = raster.GetNoDataValue()
    metadata['scaleFactor'] = raster.GetScale()

    array = np.zeros((array_shape[0],array_shape[1],dataset.RasterCount),'uint8') #pre
    for i in range(1, dataset.RasterCount+1):
        band = dataset.GetRasterBand(i).ReadAsArray(0,0,metadata['array_cols'],metadata['array_rows'])
        band[band==metadata['noDataValue']] = np.nan
        band = band/metadata['scaleFactor']
        array[...,i-1] = band

    return array, metadata

In [10]: from osgeo import gdal,osr
import sys

In [11]: #RGB_geotif = 'C:\\Users\\GoGators\\Desktop\\2017_SERC_2_368000_4306000_image.tif'
SERC_RGBcam_array, SERC_RGBcam_metadata = RGBraster2array('2017_SERC_2_368000_4306000_

```

```
In [12]: print(SERC_RGBcam_array.shape)
```

```
(10000, 10000, 3)
```

```
In [13]: #Display information stored in header
         for key in sorted(SERC_RGBcam_metadata.keys()):
             print(key)
```

```
array_cols
array_rows
bands
driver
ext_dict
extent
geotransform
noDataValue
pixelHeight
pixelWidth
projection
scaleFactor
```

1.0.3 Defining the Function that will Plot any Image/Band

```
In [14]: def plot_band_array(band_array,
                             refl_extent,
                             colorlimit,
                             ax=plt.gca(),
                             title='',
                             cbar = 'on',
                             cmap_title='',
                             colormap='spectral'):
```

```
'''plot_band_array reads in and plots a single band or an rgb band combination of
```

```
-----
```

```
Parameters
```

```
-----
```

```
band_array: flightline array of reflectance values, created from h5refl2array
refl_extent: extent of reflectance data to be plotted (xMin, xMax, yMin, yMax)
colorlimit: range of values to plot (min,max). Best to look at the histogram
ax: optional, default = current axis
title: string, optional; plot title
cmap_title: string, optional; colorbar title
colormap: string, optional; see https://matplotlib.org/examples/color/colormap
```

```
-----
```

```
Returns
```


```
plots array of single band or RGB if given a 3-band
```

```
-----
```


Example:

```
plot_band_array(SERC_RGBcam_array,  
                SERC_RGBcam_metadata['extent'],  
                (1,255),  
                title='SERC RGB Camera Tile',  
                cbar='off')
```


```
plot = plt.imshow(band_array,extent=refl_extent,clim=colorlimit);  
if cbar == 'on':  
    cbar = plt.colorbar(plot,aspect=40); plt.set_cmap(colormap);  
    cbar.set_label(cmap_title,rotation=90,labelpad=20)  
plt.title(title); ax = plt.gca();  
ax.ticklabel_format(useOffset=False, style='plain'); #do not use scientific notation  
rotatexlabels = plt.setp(ax.get_xticklabels(),rotation=90); #rotate x tick labels
```



```
In [15]: plot_band_array(SERC_RGBcam_array,  
                        SERC_RGBcam_metadata['extent'],  
                        (1,255),  
                        title='SERC RGB Camera Tile',  
                        cbar='off')
```



```
In [19]: plt.hist(np.ravel(SERC_RGBcam_array[:, :, 0]), 20);  
plt.title('Histogram of SERC Camera Red Band')  
#Challenge Exercises  
#Now that you've followed along to read in and plot an RGB camera image and band, try  
  
#Plot histograms of the green and blue bands.  
plt.xlabel('Brightness'); plt.ylabel('Frequency')  
  
Out[19]: Text(0, 0.5, 'Frequency')
```



1.1 Challenge Exercises

1.1.1 1. Plotting Histograms of the Green and Blue Bands


In [20]: *#Challenge Exercises*

#Now that you've followed along to read in and plot an RGB camera image and band, try

1. Plot histograms of the green and blue bands.


```
plt.hist(np.ravel(SERC_RGBcam_array[:, :, 1]), 20);
plt.title('Histogram of SERC Camera Green Band')
plt.xlabel('Brightness'); plt.ylabel('Frequency')
```

Out[20]: Text(0,0.5, 'Frequency')



```
In [21]: plt.hist(np.ravel(SERC_RGBcam_array[:, :, 2]), 20);
plt.title('Histogram of SERC Camera Blue Band')
plt.xlabel('Brightness'); plt.ylabel('Frequency')
```

```
Out[21]: Text(0, 0.5, 'Frequency')
```



```
In [22]: import numpy as np
```

1.1.2 2.a.1-RED BAND -Minimum and Maximum Reflectance

```
In [23]: # 2.Explore the data to see what you can learn about the SERC_RGBcam_array and associ
#         a. Determine the minimum and maximum reflectance for each band. Print these va
#         HINT: Use the numpy functions np.amin() and np.amax()
```

```
min_RED = np.amin(SERC_RGBcam_array[:, :, 0])
max_RED = np.amax(SERC_RGBcam_array[:, :, 0])

print('The minimum reflectance for RED Band is', min_RED)
print('The maximum reflectance for RED Band is ', max_RED)
```

```
The minimum reflectance for RED Band is 21
The maximum reflectance for RED Band is 255
```

1.1.3 2.a.2-GREEN BAND -Minimum and Maximum Reflectance

```
In [24]: min_GREEN = np.amin(SERC_RGBcam_array[:, :, 1])
max_GREEN = np.amax(SERC_RGBcam_array[:, :, 1])

print('The minimum reflectance for RED Band is ', min_GREEN)
print('The maximum reflectance for RED Band is ', max_GREEN)
```


The minimum reflectance for RED Band is 5
The maximum reflectance for RED Band is 255

1.1.4 2.a.3-BLUE BAND -Minimum and Maximum Reflectance

```
In [25]: min_BLUE = np.amin(SERC_RGBcam_array[:, :, 2])
         max_BLUE = np.amax(SERC_RGBcam_array[:, :, 2])

         print('The minimum reflectance for RED Band is ', min_BLUE)
         print('The maximum reflectance for RED Band is ', max_BLUE)
```

The minimum reflectance for RED Band is 12
The maximum reflectance for RED Band is 255

1.1.5 2.b. Determining UTM zone


```
In [65]: # b. What UTM zone is this data in? Hint: Print out SERC_RGBcam_metadata['projection']
         image_projection = SERC_RGBcam_metadata['projection']
         #print(image_projection)
         src = osr.SpatialReference(wkt = image_projection)
         #src.ImportFromWkt(wkt)
         if src.IsProjected:
             print (src.GetAttrValue('PROJCS'))
```

WGS 84 / UTM zone 18N

1.1.6 2.c.1- Plotting RED BAND


```
In [27]: # c. Use the plot_band_array function to plot each band of the camera image separately.
         # HINT: Use slicing to extract each band (e.g., SERC_RGBcam_array[:, :, 0]).

         plot_band_array(SERC_RGBcam_array[:, :, 0],
                         SERC_RGBcam_metadata['extent'],
                         (1, 255),
                         title='SERC RED BAND Camera Tile',
                         cbar='on',
                         colormap='gray')
```



1.1.7 2.c.2- Plotting GREEN BAND

```
In [31]: plot_band_array(SERC_RGBcam_array[:, :, 1],
                        SERC_RGBcam_metadata['extent'],
                        (1, 255),
                        title='SERC GREEN BAND Camera Tile',
                        cbar='on',
                        colormap='gray')
```



1.1.8 2.c.3- Plotting BLUE BAND

```
In [32]: plot_band_array(SERC_RGBcam_array[:, :, 2],
                        SERC_RGBcam_metadata['extent'],
                        (1, 255),
                        title='SERC BLUE BAND Camera Tile',
                        cbar='on',
                        colormap='gray')
```

